



Assembly Instructions: Protective Grille for Nolden Work-/ Reversing- Light

- When mounted as work light-



1. Choose a suitable spot to mount the lamp and mark the three holes of the base-plate.
2. Drill the holes.
3. Don't forget to deburr the holes!



4. Insert the grommet in the center-hole for the cable to go through.
5. Insert the supplied bolts into the other two holes and lock the screws with washers and nuts from the inside. Then fixate the base-plate on the car by tightening the nuts.



6. Insert the cable into the center hole.

7. Put squared nuts (come with the work light) into the intended dents on either side of the light itself.



8. Join grille and spotlight together and insert into the base-plate.



9. While holding the light and grille in place put bolts (which come with the grille) into the holes on either side through the grille, the baseplate and into the nuts you previously inserted into the work light. Then tighten the bolts.



10. Now, connect the power supply on the inside of the car, using the heat-shrink connectors (contained in the fit-kit) and off you go!