



Assembly Instructions: Protective Grille for Nolden Work-/ Reversing- Light

- When mounted as reversing light-



1. Align base-plate of the grille with the holes of the stock reversing light (RL).
2. Insert the supplied bolts into the other two holes and lock the bolts with washers. Then tighten the base-plate on the car.
3. Now connect the power supply, for example with the supplied heat-shrink connectors.
4. Put squared nuts (come with the work light) into the intended dents on either side of the light itself.
5. Join grille and spotlight together and insert into the base-plate.
6. While holding the light and grille in place put bolts (which come with the grille) into the holes on either side through the grille, the baseplate and into the nuts you previously inserted into the lamp. Then tighten the bolts.